



Care Instructions

The **Krono Original collection** of laminate flooring is virtually maintenance free. All it needs to restore its lustre after most incidents is a wipe with a damp cloth. For really tough stains, we recommend using a little acetone. Avoid using excess water as it will damage your flooring and always clean up spillages immediately. To keep your laminated floor in good condition, be sure to:

- **Use the floor exclusively under the recommended conditions.**
- **Put down a mat or rug to eliminate the risk of marks (gravel, soil, etc.) inside doorways and around sinks, etc, to protect from spillages.**
- **Move furniture carefully to avoid damaging the laminated surface.**
- **Felt pads are recommended under chairs and heavy furniture.**

| STAIN | CLEAN USING |
|--|--|
| Tar, crayon, ink, shoe polish or cigarettes. Chewing gum or candle wax. Tea, coffee, grease or wine. | Methylated spirit, acetone or household solvent. Allow to harden and then carefully scrape off. Damp cloth and mild detergent. Avoid using excess water, it will damage your flooring. Always clean up spillages immediately. |

DO NOT USE BLEACH, WAX, POLISH OR SCOURING MATERIALS

Guidelines and Important Notes

- **Double check all measurements to ensure you have the correct amount of flooring.**
- **We recommend you add a further 10% in your measurements for cutting waste.**
- **Store panels flat (horizontally) in unopened packaging for at least 48 hours (min 18c to 20 c).**
- **Check all panels for any faults as claims will not be accepted for damage or visual defects after installation.**
- **Make sure you have all tools (a hammer, saw, ruler and set square, plus instructions) to hand before starting. It is also recommended that a face mask is worn when cutting the flooring.**
- **You will need a laminate floor fitting kit and a suitable hard floor underlay. On concrete floors, a plastic film moisture barrier (of 0.2mm thick) must be laid before the underlay.**
- **Make sure the surface is DRY, FIRM and LEVEL.**
- **A floor is considered flat if the deviation in height is less than 2mm over a distance of 1 linear metre. Deviations above this must be levelled out before laying the floor.**
- **It is imperative that the fitting instructions are carefully read before commencing installation**